
INSTRUCTIONS

BARISTA TOOLS


Kit code: PLA2202

PL62 · PL62S · PL62T
PL62-W · PL62X all models

Disassembly instructions of plastic/wood components.




PL62S



PL62 / PL62T / PL62-W / PL62X all models*


*The components on the drawing are indicative, as the components you may find on the machine have undergone some minor modifications in production over the years.



Remove the cap **A** / [A] by using a flat screwdriver.

Remove the locking ring **B** / [B] by using a flat screwdriver.

Turn the knob **D** / [E] clockwise, to remove it from the tap (for PL62S* models, also remove the spacer **E**). Repeat the procedure from [1] to [3] in order to disassemble the knob for the steam wand.



Turn the lever knob anticlockwise to remove it from the extraction lever.

Follow us on **YouTube**


LELIT.COM

©2024 LELIT srl. All Rights Reserved

INSTRUCTIONS


BARISTA TOOLS

Assembly instructions of wood components.




GENERAL WARNINGS


- Store the packaging material (plastic bags, carton, foam polyurethane,etc.) out of the reach of children.
- Caution: the product includes small parts.To prevent the risk of suffocation, keep the product out of the reach of children.
- The wood accessories must not be immersed in water, washed in dishwasher or with aggressive cleaning detergents.




Screw the knob 5 on the tap.




Insert the spacer 4 into the hole of the knob 5



Insert the locking ring 3 on the stem of the tap.



Insert the cap 1 with o-ring 2 into the knob 5. Repeat the procedure from 1 to 4 in order to install the 2nd knob.



Screw the black wood lever knob on the extracion lever.

Follow us on **YouTube**

LELIT.COM

©2024 LELIT srl. All Rights Reserved